fluttering bird fun toy
quick assembly

attach bird toy

remove cap to insert wand into base

Save plastic cap and reattach when wand is used without the base.

press down on lever to lock suction-cup base to a smooth, flat surface

press down on plastic ring to release wand from the base

If you have any questions or concerns about this product contact our customer service department at 1-800-295-2243 Mon-Fri 8:00 – 4:00 MST or email us at hello@warepet.com